

VIEW OF BOMB IN PLACE



VIEW OF BOMB BEING HOISTED

LET	ALTERATION	DATE	BY	LET	ALTERATION	DATE	BY

APPROVED FOR TOOLING BY RB HUMPHREYS 1-2-43

H 51

MCR 126-2

NOTES:

1. FOR INTERNAL ADAPTER ARRANGEMENT SEE DWG. 28A6202
2. FOR EXTERNAL ADAPTER ARRANGEMENT SEE DWG 28A5201
3. HOISTING OPERATIONS ARE THE SAME FOR INTERNAL & EXTERNAL BOMB RACKS.

PART NO.	STOCK	MATERIAL	SPEC.	-0 REQ.	-2 REQ.	-3 REQ.	-4 REQ.	-5 REQ.

PARTS LIST FOR ASSY.

RAY-5 | 28210 CB
MODEL | NEXT ASSY
REQUIREMENTS FOR AIRPLANE
REPLACES
REPLACED BY
SCALE NONE
STAMP PART NUMBER WHERE SHOWN

AG
NAVY NONE | NONE
HEAT TREAT | FINISH
12-24-42 DRAFT | CHECK | STRUCT | MAT | APPVD | ENG

NAME HOISTING INSTRUCTIONS - ARMT - BRITISH BOMB ADAPTER

CONSOLIDATED AIRCRAFT CORP. San Diego Calif.

J 28A5207